

## Lock systems



### Comfort handle

#### With security lock insert E1

Only for use with **VW, Audi, SEAT, SkodaAuto**.  
Supplied without key.  
Length: 295 mm.  
Other VW locks available on request.

Design	Model No. TS
RAL 7032	<b>8611.040</b>
RAL 7035	<b>8611.045</b>

#### ! Also required:

Handle adaptor for mounting on a TS glazed door, PC-TS bottom door, IW designer door, IW glazed door, see page 934.  
Mounting adaptor for mounting on a designer glazed door 180°, see page 935.



### Comfort handle

#### for semi-cylinder

Prepared for the installation of commercially available semi-cylinders, 40 or 45 mm total length, to DIN 18 252, see page 957, as well as SZ lock and push-button inserts, see page 948.  
Length: 302 mm.

Design	Model No. TS
RAL 7032	<b>8611.060</b>
RAL 7035	<b>8611.070</b>
RAL 8019	<b>8611.270</b>
RAL 9005	<b>8611.360</b>
Matt nickel-plated	<b>8611.340</b>

#### ! Also required:

Handle adaptor for mounting on a TS glazed door, PC-TS bottom door, IW designer door, IW glazed door, see page 934.  
Mounting adaptor for mounting on a designer glazed door 180°, see page 935.



### Lock and push-button inserts

For installation in

- Comfort handle for semi-cylinders, see above,
- Ergoform-S standard, see page 953
- Folding lever handle for CM, see page 949

Design	Model No. SZ
Security lock insert no. 3524 E	<b>2467.000<sup>1)</sup></b>
Push-button insert	<b>2468.000</b>
Lock and push-button insert, lock no. 2123; no other lock is possible	<b>2469.000<sup>1)</sup></b>

<sup>1)</sup> with 2 keys

#### ⇄ Possible alternative:

Semi-cylinder, see page 957.



### Comfort handle

#### Prepared for ASSA lock system.

Length: 302 mm.

Design	Model No. TS
RAL 7032	<b>8611.050</b>
RAL 7035	<b>8611.280</b>

#### ! Also required:

Handle adaptor for mounting on a TS glazed door, PC-TS bottom door, IW designer door, IW glazed door, see page 934.  
Mounting adaptor for mounting on a designer glazed door 180°, see page 935.